

Installation Instructions

CP030200495

[Fits: BMW X5 2019-2026, BMW X6 2020-2026, BMW X7 2019-2026]

Thank you for your purchase! Please contact us for any issues!

Hardware List:

2 x Self-Tapping Screws

2 x Washers

Tools Needed:

Allen Wrench



Note 1 When you receive this product, we recommend you that you should check the hardware before installation.

Note 2 The password code should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Remove the **2 SCREWS** at the bottom of the armrest box.

STEP 3 Insert the USB line into the USB connector at the bottom of the armrest box.

STEP 4 Open the lid of the safe and put the safe into the armrest box, make sure that the 2 holes at the bottom of the safe line up with the factory holes in the armrest box.

STEP 5 Use the Allen Wrench to tighten the screws via the reserved the holes of the safe into the armrest box. Do not overtighten the screws.

STEP 7 Replace the padding in the floor of the safe.

DO NOT OVER-TIGHTEN, over tightening may also result in armrest safe damage.