

# Installation Instructions

**CP030200961**

**[Fits: 2021~2026 Tesla Model X&S]**

**Thank you for your purchase! Please contact us for any issues!**

## Hardware List:

4 pcs Self Drilling Screws

## Tools Needed:

Phillips Screwdriver

Punching Cone



**Note 1** When you receive this product, we recommend that you check the hardware before installation.

**Note 2** The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

## Safe installation:

**STEP 1** Empty the armrest box including the factory padding at the bottom.

**STEP 2** Take out the padding from the safe also. (*set aside for Step 6*)

**STEP 3** Orient the safe so that the lock is towards the rear of the vehicle. Place the Console safe inside the front compartment of the console.

**STEP 4** Use the Punching Cone to pierce small holes on the inner wall of the armrest box through the reserved holes of the safe.

**STEP 5** Insert the 4 SELF-DRILLING SCREWS by hand, and use a Phillips Screwdriver to tighten the screws! DO NOT OVER TIGHTEN, Overtightening will damage the fitting.

**STEP 6** Replace the padding removed in Step 3

**Enjoy your purchase! Any issues please contact us!**