

Installation Instructions

CP030200962

[Fits: 2021~2026 Tesla Model X&S]

Thank you for your purchase! Please contact us for any issues!

Hardware List:

4 pcs Self Drilling Screws

Tools Needed:

Phillips Screwdriver

Punching Cone



Note 1 When you receive this product, we recommend that you check the hardware before installation.

Note 2 The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory padding at the bottom.

STEP 2 Take out the padding from the safe also. (*set aside for Step 6*)

STEP 3 Orient the safe so that the lock is towards the rear of the vehicle. Place the Console safe inside the front compartment of the console.

STEP 4 Use the Punching Cone to pierce small holes on the inner wall of the armrest box through the reserved holes of the safe.

STEP 5 Insert the 4 SELF-DRILLING SCREWS by hand, and use a Phillips Screwdriver to tighten the screws! DO NOT OVER TIGHTEN, Overtightening will damage the fitting.

STEP 6 Replace the padding removed in Step 3

Enjoy your purchase! Any issues please contact us!