

# INSTALLATION INSTRUCTIONS

CP030200970

[fit 2007~2025 Toyota FJ Cruiser]

**Thank you for purchasing our products! Please contact us for any issues!**

## Hardware List:

- 2 Bolts

## Tools Needed:

- Socket wrench



**Note 1** When you receive this product, we recommend that you check the hardware before installation.

**Note 2** The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

## Safe installation:

**STEP 1** Empty the armrest box including the factory padding at the bottom.

**STEP 2** Use the wrench to remove the **2 FACTORY BOLTS** from the bottom of the armrest box.

**STEP 3** Place the safe into the armrest box. To ensure that 2 holes in the base of the safe should align with the holes in the armrest box.

**STEP 4** Use a wrench to tighten the bolts with the washers. DO NOT over-tighten, over-tightening may damage the console.

**STEP 5** Place the padding in the floor of the safe.

**Enjoy your purchase! Any issues please contact us!**