

INSTALLATION INSTRUCTIONS

CP030201328

[for Ford Maverick 2022-2026]

Thank you for purchasing our products! Please contact us for any issues!

Accessories List

- 4 pcs Self Tapping Screws
- 4 pcs Nuts

Tools Needed:

- Phillips Screwdriver
- Punching cone
- Open-end wrench



Note 1 When you receive this product, we recommend that you should check the accessories before the instruction.

Note 2 The password codes or fingerprints should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation

STEP 1 Clear out the contents of the center console (armrest box), including the factory mat at the bottom of the armrest box.

STEP 2 Place the two side brackets into the armrest box, pay attention to the brackets, the right and left brackets are different.

STEP 3 Open the lid of the safe and put the top panel of the safe on the brackets, and make sure the studs of the top panel are inserted into the reserved holes of the brackets.

STEP 4 Hand the nuts on the studs of the top panel, use the wrench to tighten the nuts.

STEP 5 Use the punching cone to poke holes through reserved holes of the brackets, and use a Phillips screwdriver to tighten the screws to fix the safe into the armrest box.

STEP 6 Please contact us for any issues! Enjoy your purchase!

DO NOT OVER-TIGHTEN, over-tightening will result in armrest box damage.