

INSTALLATION INSTRUCTIONS

CP030201653

[for Dodge Charger 2025~2023

Chrysler 300 2015~2023]

Thank you for purchasing our products! Please contact us for any issues!

Accessories List:

- 4 PCS Nuts

Tools Needed:

- Wrench

Note 1 When you receive this product, we recommend that you



should check the accessories before the instruction.

Note 2 The password codes or fingerprints should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation

STEP 1 Clear out the contents of the center console (armrest box), including the factory mat at the bottom of the armrest box.

STEP 2 Take off the screws from the bottom of the armrest box.

STEP 3 Place the passenger and driver side brackets into the armrest box, make sure the reserved holes at the bottom of the brackets are aligned with the factory holes of the armrest box.

STEP 4 Insert the crews(the screws take off in the step2) into the reserved holes at the bottom of the brackets, and then use the wrench tighten the screws into the armrest box.

STEP 5 Place the top panel over the brackets, open the lid of the console safe. Make sure the studs of top panel into the holes of the reserved of the holes of the brackets. Hand the nuts over the studs and tighten the nuts. **DO NOT OVER-TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE CONSOLE.**

STEP 6 Put back the mat into the armrest box.

STEP 7 Enjoy your purchase! Any issues please contact us!