

INSTALLATION INSTRUCTIONS

CP030202063

[for Nissan Titan 2016~2025]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 PCS Self Tapping Screws
- Pin tool
- 2 PCS keys



Tools Needed:

- Punching cone
- Phillips Screwdriver

Note 1 When you receive this product, we recommend that you should check the accessories before the instruction.

Note 2 The fingerprints codes should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation

STEP 1 Open the center console armrest box and empty all contents.

STEP 2 Set the safe into the center console armrest box.

STEP 3 Use the punching cone to poke holes in the wall of the center console armrest box through the reserved holes of the safes.

STEP 4 Hand the Self-tapping screws into the reserved holes of the safe and use a screwdriver to tighten the screws into the center console armrest box. **DO NOT OVER-TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE CONSOLE.**

STEP 5 Enjoy your purchase! Any issues please contact us!