INSTALLATION INSTRUCTIONS

CP030202242

2019-2027 Dodge Ram 1500/2500/3500
Trim Levels that fit this safe: Bighorn, Laramie, Rebel, Tradesman, and Tradesman HFE.

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4x Self Tapping Screws
- 2x keys



- **Tools Needed:**
- Punching cone
- Phillips Screwdriver

Note 1 When you receive this product, we recommend that you check the accessories before the instructions.

Note 2 The password codes or fingerprints should be set with the DOOR OPEN to test the lock effectively without locking yourself out.

Safe installation

STEP 1 Open the armrest box and empty all contents.

STEP 2 Set the safe into the armrest box.

STEP 3 Use the punching cone to poke holes in the wall of the armrest box through the reserved holes of the safes.

STEP 4 Hand the Self-tapping screws into the reserved holes of the safe and use a screwdriver to tighten the screws into the armrest box. **DO NOT OVER-TIGHTEN THESE SCREWS, THIS COULD DAMAGE THE ARMREST BOX.**

STEP 5 Enjoy your purchase! Any issues please contact us!