

INSTALLATION INSTRUCTIONS

CP030202249

[Fit Toyota Tundra 2022-2026,
Toyota Sequoia 2023-2026]

Thank you for purchasing our products! Please contact us for any issues

Warning: To avoid locking yourself out, first set the password with the **SAFE DOOR OPEN** and test the operation of the lock before closing the safe door.

Parts List:

2 pcs Bolts
2 pcs Washers
2 pcs keys

Tools Needed:

Socket wrench

STEP 1 Empty the back of armrest box of any content.



STEP 2 Console safe



STEP 3 Remove the factory bolts from the bottom of the armrest box. Put the console safe into the back of the armrest box, ensure the reserved holes of the safe line up with the holes in the bottom of the armrest box.



STEPS 4 Use a wrench to tighten the bolts with the washers. Don't over-tightening the screws and over-tighten cause damage to the armrest box.



STEP 5 You're All Set!

Close the safe lid—your installation is complete. Enjoy the added security for your vehicle!
Need Help? We're Here for You.

Your satisfaction is our priority. If you have any questions or issues with the installation or product, please contact our friendly support team via email. **We will get back to you within 24 hours.**