

INSTALLATION INSTRUCTIONS

CP030202253

[2015-2020 Ford F150, 2015-2022 Ford F250, F350, 2017-2023 Ford Super Duty, 2018-2022 Ford Expedition with Full Floor Console]

Thank you for purchasing our products! Please contact us for any issues!

Accessories List:

- 4 pcs Self-Tapping Screws
- 4 pcs Nuts
- 2 pcs Keys



Tools Needed:

- Open-end Wrench
- Punching Cone
- Phillips Screwdriver

Note 1 When you receive this product, we recommend that you check the accessories before the instructions.

Note 2 The password codes or fingerprints should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory mat at the bottom.

STEP 2 Place the top panel of the safe **into the armrest box through the diagonal of the** armrest box. Then **open the lid and raise the panel to the top of the armrest box.**

STEP 3 Put the brackets into the armrest box through the safe door. Note there are two studs on both sides of the top panel. Confirm the reserved holes of the brackets are attached to the studs of the panel.

STEP 4 Hand **Nuts** on the studs of the panel, then use an Open-end wrench to tighten the nuts. Do not overtighten the nuts, overtightening will damage the studs.

STEP 5 Use the punching cone to poke small holes in the wall of the armrest box through the reserved holes of the safe.

STEP 6 Use the Screwdriver to screw the **Self-tapping Screws** through the reserved holes of the safe into the armrest box. Also do not overtighten the screws.

STEP 7 Enjoy your purchase. Any issues please contact us.