

Installation Instructions

CP030202289

[Fits: Chevy Tahoe, Suburban & GMC Yukon, Yukon XL, Denali 2021~2026]

Thank you for your purchase! Please contact us for any issues!

Hardware List:

2 pcs Rubber mat
2 pcs Bolts
2 pcs Washers

Tools Needed:

Wrench



Note 1 When you receive this product, we recommend that you check the hardware before installation.

Note 2 The password should be set with the **DOOR OPEN** to test the lock effectively without locking yourself out.

Safe installation:

STEP 1 Empty the armrest box including the factory padding at the bottom.

STEP 2 Use the wrench to remove the **2 FACTORY BOLTS** from the bottom of the armrest box.

STEP 3 Place the rubber mats over the reserved holes at the bottom of the armrest box.

STEP 4 Place the safe into the armrest box. To ensure that 2 holes in the base of the safe should align with the holes in the armrest box.

STEP 5 Use a wrench to tighten the bolts with the washers. DO NOT over-tighten, over-tightening may damage the console.

STEP 6 Place the padding in the floor of the safe.

Enjoy your purchase! Any issues please contact us!