INSTALLATION GUIDE
CP030202612

[for 2025 Subaru Forester *Please note, this safe is not compatible with 2025 Subaru Forester Wilderness]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 4x Self-tapping screws
- 2x Keys

Tools Needed:

- Punch tool
- Phillips Screwdriver



Before You Begin:

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 **Always set your lock combination with the door OPEN** to prevent accidental lockouts. Test the combination 3-5 times to ensure proper function.

Installation Steps

1. Prepare Armrest Box

- Remove all items from the armrest box

2. Prepare Safe Interior

- Open safe door
- Remove the interior padding *(set aside for Step 6)*

3. Position Safe

- Place the safe into the console armrest box.

4. Locate the Pre-Drilled Holes

- Identify the pre-drilled holes on the inner walls of the safe.
- Use the provided punch tool to create pilot holes in the console box wall through these pre-drilled holes.

5. Secure Safe

- Place the self-tapping screws into the pre-drilled holes created in the previous step.
- Use included Screwdriver to secure screws

⚠ **Caution:** Overtightening may damage console

6. Restore Interior

- Replace all padding removed in Step 3