

INSTALLATION GUIDE

CP030202652

[for Mazda CX-5 2017-2025]

Thank You for Your Purchase! Need help? Contact us!

Parts list:

- 4x Self-tapping Screws
- 4x Acorn Dome Cap Nut
- 2x Backup keys
- 1x Pin tool

Tools Needed:

- Punching cone
- Phillips Screwdriver
- L-Shaped Hex Socket Wrench



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

 Always **set your fingerprint codes** with the **door open** to avoid accidental lockouts. **Test your code** 3–5 times to ensure proper operation **BEFORE** installing the safe in your vehicle.

Installation Steps

1. Prepare Armrest Box

- ▶ Remove all items from the armrest box

2. Prepare Safe

- ▶ 1x Top panel, 2x side brackets
- ▶ Note the brackets are different

3. Position the brackets

- ▶ Insert the brackets into the armrest box.

4. Position the top panel

- ▶ Align the top panel studs with the two holes on top of the brackets, then secure the panel with the brackets using the acorn dome cap nuts(included) with wrench(included).

5. Secure the brackets

- ▶ Use the punch tool to mark pilot holes through the bracket holes onto the box wall.
- ▶ Place the self-tapping screws into the reserved holes created and use included screwdriver to secure screws. Finish the installation.

 **Caution:** Over-tightening may damage console

