

INSTALLATION GUIDE

CP030202654

[for Chevy Equinox 2025-2026]

Thank You for Your Purchase! Need help? Contact us!

Parts list:

- 4x Self-tapping Screws
- 2x Backup Keys

Tools Needed:

- Punching cone
- Phillips Screwdriver



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:



Always set your lock combination with the door OPEN to prevent accidental lockouts. Test the combination 3-5 times to ensure proper function.

Installation Steps

1. Prepare the Armrest Box

- ▶ Remove all items from the armrest box.
- ▶ Take out the factory floor mat.

2. Prepare the Safe Interior

- ▶ Open the safe door.
- ▶ Remove the interior padding and set it aside for Step 6.

3. Position the Safe

- ▶ Place the safe inside the center armrest box.
- ▶ Make sure it is centered and level.

4. Secure the Safe

- ▶ Use the included punching tool to create guide holes in the armrest box wall by pressing through the safe's pre-drilled holes.
- ▶ Hand-start the self-tapping screws in the pre-drilled holes.

5. Final Tightening

- ▶ Use the included Phillips screwdriver to fully secure the screws.



Caution: Do not overtighten—this may crack or damage the armrest box.

6. Restore the Interior

- ▶ Put back all padding removed in Step 2.