

INSTALLATION GUIDE

CP030202700

[for BMW X3 2025-2026]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Self-tapping screws
- 1x Pin tool
- 2x Backup keys

Tools Needed:

- Allen wrench

Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

 **Always set your lock fingerprint code with the door OPEN** to prevent accidental lockouts. Test the fingerprint code 3-5 times to ensure proper function.

Installation Steps

1. Prepare Armrest Box

- ▶ Remove all items from the armrest box
- ▶ Take out the factory floor mat

2. Remove Mounting Bolts

- ▶ Locate and remove the **2 console bolts** from the bottom of the armrest box

3. Prepare Safe Interior

- ▶ Open safe door
- ▶ Remove the interior padding (*set aside for Step 7*)

4. Position Safe

- ▶ Align safe's mounting holes with console's factory holes
- ▶ Ensure proper fit before securing

5. Secure Safe

- ▶ Insert provided self-tapping screws

6. Final Tightening

- ▶ Use included wrench to secure screws

 **Caution:** Overtightening may damage console

7. Restore Interior

- ▶ Replace all padding removed in Step 3