

INSTALLATION GUIDE

CP030202951

[for Silverado/GMC Sierra 2007-2013]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Self-tapping screws
- 2x Washers
- 1x Pin tool
- 2x Keys

Tools Needed:

- Phillips Screwdriver



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:



Always set your Fingerprint codes with the door OPEN to prevent accidental lockouts. Test the codes 3-5 times to ensure proper function.

Installation Steps

1. Prepare Armrest Box

- ▶ Remove all items from the armrest box
- ▶ Use the Phillips Screwdriver (provided) to remove screws from the bottom of the armrest box.

2. Prepare Safe

- ▶ Open safe door, remove the padding, and set it aside.

3. Position Safe

- ▶ Position the safe inside the armrest box, aligning its mounting holes with the vehicle's factory screw holes.

4. Secure Safe

- ▶ Place the screws with the washers into the mounting holes
- ▶ Use the included Screwdriver to secure screws.

5. Place the padding

- ▶ Remove the backing from the adhesive strips on the padding (removed in Step 2) and secure it to the interior of the safe.



Caution: Overtightening may damage console