

INSTALLATION GUIDE

CP030202988

[for Toyota Camry 2012-2017]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Self-tapping screws
- 2x Washers
- 1x Pin tool
- 2x Keys

Tools Needed:

- Phillips Screwdriver



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:



Always set your Fingerprint codes with the door OPEN to prevent accidental lockouts. Test the fingerprint 3-5 times to ensure proper function.

Installation Steps

1. Prepare Armrest Box

- ▶ Remove all items from the armrest box
- ▶ Use a tool to take off the screws from the bottom of the armrest box

2. Prepare Safe

- ▶ Open safe door, remove the padding, and set padding aside.

3. Position Safe

- ▶ Identify the reserved mounting holes at the bottom of the safe.
- ▶ Place the safe into the console armrest box.
- ▶ Make sure to align the mounting holes in the safe with the factory holes in the armrest box.

4. Secure Safe

- ▶ Place the self-tapping screws with washers into the mounting holes.
- ▶ Use included Screwdriver to secure screws

5. Place the padding

- ▶ Return the padding (removed in Step 2) to the interior of the safe.



Caution: Over-tightening may damage console