

INSTALLATION GUIDE

CP030203029

[for Hyundai Palisade 2026+]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Bolts
- 2x Washers
- 1x Pin tool

Tools Needed:

- L-Shaped Hex Socket Wrench



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

 Always **set your password** with the **door open** to avoid accidental lockouts. **Test** the password 3–5 times to ensure proper operation **BEFORE** installing the safe in your vehicle.

Installation Steps

1. Prepare Armrest Box

- Remove all items from the armrest box
- Use the L-shaped Hex Socket Wrench (provided) to remove bolts from the bottom of the armrest box.

2. Prepare Safe

- Open safe door, remove the padding, and set it aside.

3. Position Safe

- Position the safe inside the armrest box, aligning its mounting holes with the vehicle's factory screw holes.

4. Secure Safe

- Place the screws with the washers into the mounting holes
- Use the included Wrench to secure screws.

5. Place the padding

- Return the padding (removed in Step 2) to the interior of the safe.

 **Caution:** Over tightening may damage console