

INSTALLATION INSTRUCTIONS

CP030203046

[for Chevrolet Silverado 2019-2024 Under Rear-seat]

Thank you for purchasing our products! Please contact us for any installation issues!

Parts List:

- 4 pcs M8 Stainless Steel 201 Lock Nuts
- 4 pcs M8 Stainless Steel 201 Flat Washers
- 4 pcs M8 Stainless Steel 201 Chamfered Hex Socket Head Cap Screws
- 1 pc Pin Tool (for fingerprint lock)
- 2 pcs Fingerprint lock keys & 2 pcs 4-digit lock keys
- 1 pc Passenger-side & 1pc Driver-side mounting brackets (in lockbox)

Tools Required:

- Open-end wrenches
- Hex key/ Allen key

Notes:

1. Pre-installation Check: Verify all accessories and read instructions thoroughly before installation.
2. Bracket Preparation: Remove mounting brackets from the safe interior before beginning.

Installation steps

STEP 1 Lift the rear seat to expose the underside.

STEP 2 Turn the jack' s red release valve counterclockwise to loosen, then remove and store the jack properly.

STEP 3 Remove the tire tool kit secured beside the jack and store kit properly.

STEP 4 Remove the factory mounting bracket under the jack.

STEP 5 Remove the factory storage box.

STEP 6 Use an open-end wrench to loosen and remove the OEM seat mount bolts.

STEP 7 (Passenger Side) Gently raise the rear seat cushion to create clearance, then slide the safe mounting bracket under the seat support structure.

STEP 8 Position the safe passenger-side mounting bracket beneath the seat support structure, ensuring its straight edge faces outward.

STEP 9 Reinsert the OEM seat mount bolt (remove from Step 6) but do not tighten it.

STEP 10 Repeat steps 7- 9 on the driver side.

STEP 11 Place the safe into the vehicle floorboard cavity, engaging it with the installed brackets until fully seated.

STEP 12 Open the safe lid, align the bracket holes with the safe' s pre-drilled holes for precise positioning.

STEP 13 Secure the safe using provided screws, flat washers, and lock nuts.

STEP 14 Tighten all OEM seat mount bolts to specification.

STEP 15 Reinstall the vehicle jack to its designated mounting location.

STEP 16 Reinstall the tire tool kit to its designated mounting location.

STEP 17 For assistance, contact technical support or refer to the installation video guide.