

INSTALLATION GUIDE

CP030203996

[for 2026+ Mercedes-Benz G-Wagon]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 4x Self-tapping screws
- 4x Flange Nuts
- 1x Pin tool

Tools Needed:

- Punch tool
- Phillips Screwdriver
- Pipe Handle Socket Wrench



Before You Begin:

- ✓ **Check Parts** – Verify all included components before starting.
- ✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 Always **set your password** with the **door open** to avoid accidental lockouts. **Test** the password 3–5 times to ensure proper operation **BEFORE** installing the safe in your vehicle.

Installation Steps

1. Prepare Console

- Remove all items from the center console

2. Prepare Safe

- 1x Top panel, 2x side brackets
- Note the brackets are different

3. Position the top panel

- Place the top panel into the center console.

4. Secure the top panel and side brackets

- Open the lid, then set the left and right side brackets underneath the top panel separately
- Hook the U-shaped slots on the side brackets onto the studs of the top panel
- Place the flange nuts onto the studs and tighten them with the supplied offset box wrench.

5. Secure the brackets

- Use the punch tool to mark pilot holes through the bracket holes onto the console wall.
- Place the self-tapping screws into the pre-drilled holes created and use included screwdriver to secure screws. Finish the installation.

⚠ **Caution:** Over-tightening may damage console

