INSTALLATION INSTRUCTIONS

CP030201046

[Toyota Hilux 2016-2025]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 4 pcs Screws
- 4 pcs Stainless steel hexagon riveted nut

Tools Needed:

- Wrenches

Note 1 When you receive this product, we recommend that you check the accessories before the instructions.

Note 2 The password codes or fingerprints should be set with the DOOR OPEN to test the lock effectively without locking yourself out.

Safe installation

STEP 1 Open the armrest box and empty all contents.

STEP 2 Place the Top Panel into the armrest box and try to place the panel on the top of the armrest box.

STEP 3 Open the Lid and put the Side Panels under the top panel. And verify the studs of the lid is inserted accurately into the reserved holes of the side panels.

STEP 4 Hand the 4 stainless steel hexagon riveted nut on the studs of the top panel. Use the wrench to tighten the nuts to fix the panel on the brackets.

STEP 5 Hand the screws into the reserved holes of saft bottom, use the wrench to tighten the screws into the bottom of the armrest box. Put the mat into the safe.

STEP 6 Enjoy your purchase! Any issues please contact us!

Don’t overtighten the crews, overtightening may damage the safe and armrest box.