INSTALLATION INSTRUCTIONS

CP030201102

[Fit Toyota Highlander 2014~2019]

Thank you for purchasing our products! Please contact us for any issues!

Accessories List:

- 4 PCS Self-Tapping Screws
- 4 PCS Acorn Nuts

Tools Needed:

- Phillips Screwdriver
- Open-end wrench

Note 1 When you receive this product, we recommend that you should check the accessories before the installation.

Note 2 The password should be set with the DOOR OPEN to test the lock effectively without locking yourself out.

Safe Installation:

STEP 1 Clear out the contents of the center console (armrest box).

STEP 2 Place the top panel into the armrest box, hold the tope panel at the top of the armrest box.

STEP 3 Open the lid of the safe, put the Panel Baffle to the back of the panel through the safe door. Make sure the reserved holes of the baffle are cover through the studs of the top panel.

STEP 4 Hand the nuts on the studs of the top panel, use the wrench to tighten the nuts.

STEP 5 Push the self-tapping screw into the reserved holes of the panel, and use a Phillips screwdriver to tighten the screws to fix the safe into the armrest box.

STEP 6 Please contact us for any issues! Enjoy your purchase!

DO NOT OVER-TIGHTEN, over-tightening will result in armrest box damage.