INSTALLATION INSTRUCTIONS

CP030201656

[for Volkswagen Atlas 2018~2023]

Thank you for purchasing our products! Please contact us for any issues!

Parts List:

- 2 PCS M6*35 Bolts

  2 PCS Washers

Notes:

Note 1 When you receive this product, we recommend that you should check the accessories before the instruction.

Note 2 The combination codes or fingerprint codes should be set with the DOOR OPEN in order to test the lock combination effectively without locking yourself out.

Safe installation

STEP 1 Clear out the contents of the console armrest box.

STEP 2 Remove the 2 BOLTS at the bottom of the console armrest box.

STEP 3 Remove the padding from the inside of the safe.

STEP 4 Set the safe into the console armrest box.

a. To ensure the safe is set in the console properly, make sure that the factory reserved holes at the bottom of the safe **LINE UP** with the factory screw holes in the console armrest box from **STEP 2**.

STEP 5 Place the 2 BLOTS with washers through the bottom of the safe into the factory screw holes at the bottom of the armrest box.

STEP 6 Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.

STEP 7 Enjoy your purchase!

Tools Needed:

- Impact drill or Socket wrench