INSTALLATION GUIDE
CP030202950

[for **Silverado/GMC Sierra 2007-2013**]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Self-tapping screws
- 2x Washers
- 1x Pin tool

Tools Needed:

- Phillips Screwdriver

Before You Begin:

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 **Always set your Password with the door OPEN** to prevent accidental lockouts. Test the password 3-5 times to ensure proper function.

Installation Steps

1. Prepare Armrest Box

- Remove all items from the armrest box
- Use the Phillips Screwdriver (provided) to remove screws from the bottom of the armrest box.

2. Prepare Safe

- Open safe door, remove the padding, and set it aside.

3. Position Safe

- Position the safe inside the armrest box, aligning its mounting holes with the vehicle's factory screw holes.

4. Secure Safe

- Place the screws with the washers into the mounting holes
- Use the included Screwdriver to secure screws.

5. Place the padding

- Remove the backing from the adhesive strips on the padding （removed in Step 2） and secure it to the interior of the safe.

⚠ **Caution:** Overtightening may damage console