INSTALLATION GUIDE
CP030202987

[for Toyota Camry 2012-2017]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Self-tapping screws
- 2x Washers
- 1x Pin tool

Tools Needed:

- Phillips Screwdriver

Before You Begin:

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 **Always set your Password with the door OPEN** to prevent accidental lockouts. Test the password 3-5 times to ensure proper function.

Installation Steps

1. **Prepare Armrest Box**
   - Remove all items from the armrest box
   - Use a tool to take off the screws from the bottom of the armrest box
2. **Prepare Safe**
   - Open safe door, remove the padding, and set padding aside.
3. **Position Safe**
   - Identify the reserved mounting holes at the bottom of the safe.
   - Place the safe into the console armrest box.
   - Make sure to align the mounting holes in the safe with the factory holes in the armrest box.
4. **Secure Safe**
   - Place the self-tapping screws with washers into the mounting holes.
   - Use included Screwdriver to secure screws
5. **Place the padding**
   - Return the padding (removed in Step 2) to the interior of the safe.

⚠ **Caution:** Over-tightening may damage console