INSTALLATION GUIDE
CP030204097

[for Cadillac XT5/XT6 2020-2026]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 4x Self-tapping screws
- 2x Keys
- 1x Pin tool

Tools Needed:

- Punch tool
- Phillips Screwdriver

Before You Begin:

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 **To prevent lockouts:** program your fingerprint with the door open. **Test the fingerprint 3–5 times** before installing the safe in your vehicle.

Installation Steps

1. Prepare Armrest Box

- Remove all items from the console armrest box

2. Prepare Safe

- Open safe door, remove the padding, and set it aside.

3. Position Safe

- Place the safe into the console armrest box.

4. Locate the reserved mounting Holes

- Identify the reserved mounting holes on the frames of the safe.
- Use the provided punch tool to create pilot holes in the console box wall through these reserved holes.

5. Secure Safe

- Place the self-tapping screws into the holes created in the previous step.
- Use included Screwdriver to secure screws.

6. Place the padding

- Return the padding (removed in Step 2) to the interior of the safe.

⚠ **Caution:** Over-tightening may damage the console box.