# INSTALLATION GUIDE
# CP030204200

[for Volvo XC40 2019-2026/C40 2022-2026]

**Thank You for Your Purchase! Need help? Contact us!**

**Parts List:**

- 4x Self-tapping screws
- 2x keys
- 1x Pin tool

**Tools Needed:**

- Punch tool
- Phillips Screwdriver

**Before You Begin:**

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

**Safety Notice:**

🔒 Always **set your password** with the **door open** to avoid accidental lockouts. **Test** the password 3–5 times to ensure proper operation **BEFORE** installing the safe in your vehicle.

---

**Installation Steps**

**1. Prepare Armrest Box**

- Remove all items from the armrest box

**2. Prepare Safe**

- Open safe door, remove the padding, and set it aside.

**3. Position Safe**

- Fit the safe into the console armrest box.

**4. Mark the pilot Holes**

- Locate the reserved holes on the frame of the safe.
- Use the provided punch tool to pierce pilot holes in the console box wall through these reserved holes.

**5. Secure Safe**

- Place the self-tapping screws into the holes created in the previous step.
- Use included Screwdriver to secure screws

**6. Place the padding**

- Return the padding (removed in Step 2) to the interior of the safe.

⚠ **Caution:** Over-tightening may damage the console. Tighten just until snug.