INSTALLATION GUIDE
CP030204855

[for **Mazda CX-30 2020-2026**]

Thank You for Your Purchase! Need help? Contact us!

Parts List:

- 2x Bolts
- 2x Washers
- 1x Pin tool

Tools Needed:

- L-Type Socket Wrench

Before You Begin:

✓ **Check Parts** – Verify all included components before starting.

✓ **Review Instructions** – Read this guide thoroughly before installation.

Safety Notice:

🔒 Always **set your password** with the **door open** to avoid accidental lockouts. **Test** the password 3–5 times to ensure proper operation **BEFORE** installing the safe in your vehicle.

Installation Steps

1. **Prepare Armrest Box**
   - Remove all contents from the armrest box
   - Use the L-Type Socket Wrench (provided) to remove factory bolts from the bottom of the armrest box.
2. **Prepare Safe**
   - Open safe door, remove the padding, and set it aside.
3. **Position Safe**
   - Position the safe inside the armrest box, aligning its mounting holes with the vehicle's factory screw holes.
4. **Secure Safe**
   - Insert the supplied bolts with washers through the mounting holes and tighten firmly with the wrench.
5. **Place the padding**
   - Return the padding (removed in Step 2) to the interior of the safe.

⚠️ **Caution:** Over tightening may damage the console, tighten just until snug.